

INSTALLATION

3 D WALL PANELS

Substrate preparation:

- The substrate should be stable, dry and clean from all dirt, greasy stains and dust
- Wall panels should be installed after completing any wet renovation works in a room with a secured floor
- Correct air humidity 45% -65%
- Correct room temperature 18-22 degrees Celsius
- Before installation, it is necessary to acclimatize the panels in the conditions of the room.

Recommended installation with the use of hybrid or polymer adhesive.



1. Leaving the cartons open for 48 hours so that the panels can adapt to the climatic conditions.



2. Floor protection.



3. Wall priming.



4. Level check for the first layer. When laying out the patterns specified in the design, apply an auxiliary sketch to the wall.



5. Cleaning the edges and back surface of the panel to remove undesirable objects on the contact surfaces of the panels and the wall.



6. Applying the adhesive evenly over the entire surface of the panel.



7. Application and pressing the panel in a suitable place on the wall.



8. Clean off dust and dirt with a dry microfiber cloth. Polishing.



FORM AT WOOD | designed to touch